

Installation Instructions JLT Oil Separator 3.0 Passenger Side 2005-10 Mustang V6 #3017P

1) Remove stock PCV line you are replacing by releasing the plastic tangs and pull the hose off the fittings.



2) Remove 10MM bolt on passenger shock tower holding down the ground wire and use it to install supplied bracket.

** MAKE SURE TO PUT GROUND WIRE ON TOP OF JLT BRACKET AS SHOWN**





3) Use supplied screws to attach Separator to the bracket and hook up the hoses



To properly clean the filter in the Oil Separator spray any degreaser or solvent through it and let it air dry. Clean it every 10,000 miles. Thanks for the business. If you have any questions, please e-mail info@JLTtruecoldair.com or call 757-335-1940. Our hours are Monday-Friday. 8:00am – 5:00pm Eastern Time.

Warranty: JLT Performance Inc. will repair or replace any part of their product found upon our inspection to be defective in workmanship or material within 1 year from the purchase date for the original purchaser.

<u>Disclaimer:</u> JLT Performance Inc. makes no warranties whatsoever, expressed or implied, oral or written to any purchasers, except the warranty above. JLT Performance Inc. hereby

<u>Disclaimer:</u> JLT Performance Inc. makes no warranties whatsoever, expressed or implied, oral or written to any purchasers, except the warranty above. JLT Performance Inc. hereby specifically excludes from any implied warranty of merchantability or implied warranty of incidental, secondary, or consequential damages of any kind whatsoever. All purchasers and users of products manufactured by JLT Performance Inc. agree to hold harmless and indemnify JLT Performance Inc. from any and all claims arising from their use. Failure to receive notice of any or the limitations contained in this disclaimer shall not serve to extend liability to JLT Performance Inc. for any claims arising out of use of its products.