





Installation Instructions JLT Next Generation Ram Air Intake Kit for 1996-98 Cobra # RAI2-FMC-9698

Thank you for purchasing our product. We hope you are satisfied with the look and performance.

Verify you have all of the following parts included in the kit:

(1) JLT Intake tube with IAC & PCV fittings and IAT grommet, (1) 4.5"x2" Silicone Coupler,
(1) 4.5"-4" Silicone Reducer, (1) MAF Silicone Spacer, (1) MAF Gasket, (1) MAF Adaptor with bolts, (3) #72 Clamps,
(1) #64 clamp, (1) 4x9" Air Filter (1) Heat shield, (1) 6" 3/4" hose and (1) 12" 5/8" hose

Step#	
1	Gather all of the following tools needed for the installation: 5/16 Nut Driver, 10mm Open End Wrench, 11mm Open End Wrench
2	Remove your stock intake system from the throttle body to the filter housing. 
3	Unbolt your Mass Air Flow Sensor from the filter housing and install the MAF filter adaptor using the supplied MAF gasket and bolts shown below. BOLTS GO THROUGH MAF AND THREAD INTO ADAPTOR. Do not reuse the screen. Install MAF Silicone Spacer on round end (for use with stock 80mm MAF only).  MAF Silicone Spacer  STOCK MAF  RUBBER MAF GASKET IN BETWEEN BOLT MAF ADAPTOR
4	Install the filter onto the MAF adaptor and the silicone reducer onto the MAF. Next install Throttle body coupler onto JLT tube, then the tube into silicone reducer making a complete unit from throttle body to filter. 

5	PULL the Inlet Air Temperature sensor from your stock inlet and install in the grommet on bottom side of JLT tube. 
6	Tuck air filter behind the headlight and lower down onto throttle body. Tighten only the clamp on throttle body.
7	Plug in IAT sensor, MAF sensor, IAC and PCV connection. Using the stock air box bolt, install the heat shield. 
8	Go back and make any adjustments to the tube and tighten the clamps (ONLY FINGER TIGHT). Installation is complete.

Oil Filter: The frequency you should clean your filter will depend on your driving conditions. It is recommended to check your filter at every oil change or 3,000 miles. If there is a buildup of dirt as thick as the wire mesh, then it's time to clean your filter.

To properly clean your oil filter, we recommend the S&B Precision Cleaning & Oiling Kit (located in the Parts Sold Separately Section of our website, www.JLTtruecoldair.com).

Thanks for the business. If you have any questions, please e-mail info@JLTtruecoldair.com or call 757-335-1940. Our hours are Monday-Friday, 8:00am – 5:00pm Eastern Time.

JLT Performance Lifetime Satisfaction Guarantee. We want you to be a JLT Performance customer for life! Your new JLT Performance product is warranted to be free from defects in materials and workmanship for the life of the *original retail purchaser*, subject to the limitations contained in our warranty found here. www.jlttruecoldair.com/warranty

We guarantee workmanship, tunability and even a pathway to discounted upgrades for substantially improved items.

Return Policy: All returns will be subject to a 10%-25% restocking fee. Air Filters will not be accepted for return unless they are in original plastic sealed bag. Please visit www.JLTtruecoldair.com for complete return policy.

Disclaimer: JLT Performance Inc. makes no warranties whatsoever, expressed or implied, oral or written to any purchasers, except the warranty above. JLT Performance Inc. hereby specifically excludes from any implied warranty of merchantability or implied warranty of incidental, secondary, or consequential damages of any kind whatsoever. All purchasers and users of products manufactured by JLT Performance Inc. agree to hold harmless and indemnify JLT Performance Inc. from any and all claims arising from their use. Failure to receive notice of any or the limitations contained in this disclaimer shall not serve to extend liability to JLT Performance Inc. for any claims arising out of use of its products.