




1994-04 Caster Camber Plate Install



BEFORE INSTALLATION:

Refer to a service manual for your car and acquire all needed tools. These instructions are not intended to replace aptitude and mechanical knowledge. Consult a local professional if you have any question about your ability to complete the installation. Only use the supplied hardware and as always - **BE SAFE!**



ALIGNMENT RECOMMENDATIONS FOR STREET APPLICATIONS:

CASTER:

We recommend that you set your caster at the maximum positive possible, but make sure both sides are equal. (Slight adjustment may be necessary for road crown.)

CAMBER:

Most street driven vehicles will achieve good tire wear with -.5 degrees of negative camber. Depending on your driving habits you may need to adjust the camber to compensate for tire wear.

TOE:

Set toe to the factory specifications.

- 1. Raise car and place jack stands securely under front end.
- Remove front wheels & tires.
- 3. Insert floor jack under control arm and jack up until slightly loaded.
- 4. Remove upper strut mounting nut. Using an impact wrench will be helpful.
- Remove the 3 stock strut mounting bracket nuts.
- 6. Lower jack until strut shaft is down through top hole of strut tower.
- 7. Push strut down through factory hole until it clears bottom plate. Removing the strut from the vehicle may be
- Remove the bottom plate from the strut tower. Removal of the locating rivet may be necessary. 8.
- 9. Remove factory dust cover from strut.
- 10. Install new bottom plate up through 3 mounting slots of factory strut tower.
- 11. Install new top plate/bearing plate assembly making sure the slots face front to rear.
- 12. Use slot configuration in Figure 2 for stock springs or lowering springs up to .75". Use slot configuration in Figure 3 for lowering springs beyond .75" or for performance handling applications.
- 13. Use three 10mm flat washers and three 10mm nyloc nuts to loosely retain the assembly in place.
- 14. Space the strut with the supplied spacers. A good starting point is to use one 15mm spacer on the strut shaft and then slide the strut shaft in to the bearing plate.
- 15. Raise the jack to compress the suspension and lower the hood and check clearance. The goal is to get the top of the strut shaft as close to the hood as possible without hitting.
- 16. Repeat 14 and 15 as necessary. Once strut height is set, use enough spacers on top of the bearing plate to allow the nut to tighten down about 1.5" from the end of the strut shaft.
- 17. Verify strut does not bottom out internally.
- 18. Repeat for other side of vehicle
- 19. Have vehicle professionally aligned.



For a More In Depth Install Scan The QR Code For Video

Disclaimer

By using this instruction sheet, you agree that other than as expressly stated in the LMR Terms and Conditions (Agreement) or as required by the laws of the state of Texas or applicable United States federal law (Applicable Law), this instruction sheet is provided "AS IS" and LMR does not make any specific representations or warranties about this instruction sheet. For example, LMR does not make any warranties about: (a) the content provided in this instruction sheet; (b) any specific features of this instruction sheet, or its accuracy, reliability, or ability to meet your needs. The knowledge and experience level of users of this instruction sheet vary widely; if you do not have adequate knowledge and experience to use this instruction sheet and safely accomplish the tasks described, please hire a professional to assist you for your safety and the safety of your vehicle and others.

Limitation of Liability

Except as required by Applicable Law, LMR, its affiliates, officers, directors, employees and agents will not be responsible for any loss of profits, revenues, business opportunities, goodwill, or anticipated savings, indirect or consequential loss, punitive damages caused by:

- · Errors, mistakes, or inaccuracies in this instruction sheet
- Personal injury or property damage resulting from your use of this instruction sheet

This limitation of liability provision applies to any claim regardless of whether the claim asserted is based on warranty, contract, tort or any other legal theory.

Use this information at your own risk, Any injury, damage, or loss that may result from use of the tools, equipment, products, or information contained in this instruction sheet is the sole responsibility of the user.

Indemnity

To the extent permitted by Applicable Law, you agree to defend, indemnify and hold harmless LMR, its Affiliates, officers, directors, employees, agents, information providers, licensors, and other partners from and against any and all claims, obligations, losses, liabilities, costs or debt, and expenses (including but not limited to attorney's fees) arising from: (i) your use of and access to this instruction sheet; (ii) your violation of any term of the Agreement; (iii) your violation of any third party right, including without limitation any copyright, property, or privacy right; or (iv) any claim that your actions caused damage to LMR or a third party. The defense and indemnification obligations will survive this Agreement and your use of this instruction sheet.