



SB041 INSTALLATION INSTRUCTIONS

2005-2014 FORD MUSTANG

1. Lift vehicle and safely support with jack stands under the frame rails.
2. Using an 18mm socket, remove the sway bar end link nuts on the end of the sway bar. Leave the end link attached to the struts.
3. Using a 15mm socket, remove all (4) bolts on the sway bar mounting saddles then remove the sway bar.
4. Lube the inside of the 1.5" diameter bushings and install them over the BMR sway bar.
5. Slide the provided saddles over the bushings then install the bar to the factory core support using the factory hardware.
6. Re-connect the end links to the desired hole location at the ends of the sway bar.
7. Lower vehicle.



WWW.BMRSUSPENSION.COM

This product is an aftermarket accessory and not designed by the vehicles manufacturer for use on this vehicle. As such, buyer assumes all risk of any damage caused to the vehicle/person during installation or use of this product.