

FORD MUSTANG ECOBOOST BLOW OFF VALVE ADAPTOR

TOOLS REQUIRED

M5 long allen wrench

MATERIALS REQUIRED

None

1	The blow of valve location.	2	The blow of valve location.
		3	4
5	Boomba Blow Off Valve Adaptor ready for installation.		
	6		
	Reinstall the blow off valve and the adaptor with provided M6 screws. Reconnect the blow off valve harness.		