


## LRS-10313-K Instructions

- 1. Install Stud "B" into upper R/H hole location on the driver's side head. (See Figure 1)
- 2. Slide rear A/C bracket (LRS-9998927) over the Stud "B" using Hole #1 indicated in Figure 2
- 3. Install Bolt "C" through hole to mount the back bracket. (See Figure 2)
- 4. Install power steering pump to the P/S mounting bracket (LRS-9998926) using qty 3 of Bolt "A".
- 5. Slide the top hole #2 of the power steering pump bracket assembly over Stud "B". (See Figure 4)
- 6. Install Front A/C Mounting Bracket (LRS-9998929) over **Stud "B"** as well as the 3 water pump studs see Figure 4 "Note: the nuts that attach the A/C Mounting bracket to the water pump studs are included with the Water Pump Timing cover Hardware Kit LRS-8501BHDW that is sold separately"
- 7. Install QTY 1 of Bolt "D" into hole #3 indicated in Figure 4
- Install Rear A/C Support Bracket (LRS-9998928) to Angled Flange on the Rear A/C bracket (LRS-9998927) Using QTY 2 of Bolt "E"
- Use QTY 5 of Bolt "E" to finish mounting A/C compressor to Front A/C Mounting Bracket(LRS-9998929) and rear A/C support bracket (LRS-9998928) (See Figure 5)
- 10. Use QTY 1 of Bolt "G" to secure Alternator Bracketto Passenger's side head using Hole# 4 as shown on Figure 6
- 11. Use QTY 2 Bolt "F" to finish attaching alternator bracket to engine using bolt holes #5 as shown on Figure 6
- 12. QTY 1 of Bolt "D" will be used to mount lower alternator pivot in hole #6 (See Figure 6)
- 13. QTY 1 of Bolt "H" will be used to mount Smog Pump pivot in Hole #7 (See Figure 6)
- 14. Slide Rear Smog Pump Support bracket (LRS-9998930) over timing pointer stud and secure with Timing Pointer nut. "Note: Timing pointer hardware is included with Water pump timing cover hardware kit LRS-8501BHDW that is sold separately."
- 15. Use QTY 1 Bolt "A" to secure rear smog pump support bracket "LRS-9998930" to the back of the smog pump.






FIG.1




FIG.3



FIG.5




FIG.2




FIG.4

