



5030-135-CSS

5030-135-1-CSS

2015-2017 Mustang GT VMP / ROUSH Catch Can

1. On the passenger side of the car, there is a bolt that goes into the front bumper. This will be to the left of the radiator. Remove this bolt and replace it with the long bracket. Using the front hole of the bracket attached to the catch can, place it onto the stud and use the knob to secure it.
 - a. You may have to unplug the AC line and wiggle it around to fit properly.
 - b. You can remove the radiator cover to allow more room for installation.

2. Remove the line from the passenger side valve cover that T's off into the blower and connects to the rubber hose that wraps around the back of the blower
 - a. Remove all the clamps on the rubber hose.

3. Take the Plug with zip tie and insert it into the rubber hose and move this line out of the way
 - a. Zip tie to other lines and leave this line be.

4. The line with NO CHECK VALVE goes from the passenger side PCV fitting to the top of the catch can.

5. The line WITH THE CHECK VALVE goes from the fitting on the side of the can and connect to the supercharger. ARROW FACES AWAY FROM THE CAN.

6. The CSS connects on to the driver side valve cover

7. Run the short line from the CSS to the intake tube.