

TRUCK REAR SPOILER INSTALLATION INSTRUCTIONS

**Notice: Prefit Before Painting!
Painted or Altered Parts are Non-Refundable**

**Important: DO NOT fill in vent holes on underside of wing
DO NOT blow air into vent hole, it will damage the part
DO NOT peel off tape backing until after the wing has been painted**

- STEP 1. Open tailgate and remove any panels needed for the installation of the wing.
- STEP 2. Close tailgate, place spoiler on tailgate and align in proper position. Check for proper alignment (*side to side, front to back*).
- STEP 3. Mark the paint surface to locate the center of the holes to be drilled.
- STEP 4. Using a 1/4" drill bit, drill through the tailgate where holes were marked.
- STEP 5. Coat all raw or bare steel with etching primer. Allow to dry. Place spoiler on tailgate. Hold in place and install plastic screw retainers.



QTY	DESCRIPTION	PART #
(1) PER EA		
1/4" HOLE	SCREW RETAINER	WE 2460