



ATI-VPOD-76

Auto-Tech Interiors, Inc.

2 Cranberry Rd. Suite B5 Parsippany NJ 07054

Phone: 949-923-8211 Fax: 866-883-2283

INSTALLATION MANUAL

Step 1: Gently pull the driver side vent from the dash until the tabs will release. No tools are needed.

Step 2: Separate the vent by pulling the tabs and releasing them.



Step 3: Once the vent is disassembled, remove the interior vent and replace it with the ATI gauge pod insertion and reverse the disassembly process.



Step 4: Before inserting the gauge into the pod, you may need to wrap the canister of the gauge with tape to ensure tight fitment. This is due to the various tolerances each gauge manufacturer has during production.



Step 5: Once the gauge is in place and tight, you can insert the vent pod back into the dash.

AUTO-TECH INTERIORS, INC. DOES NOT WARRANT, GUARANTEE, OR MAKE ANY REPRESENTATIONS REGARDING THE USE, OR THE RESULTS OF USE, OF THIS PRODUCT. NEITHER AUTO-TECH INTERIORS, INC. NOR ANYONE ELSE WHO HAS BEEN INVOLVED IN THE CREATION, PRODUCTION OR DELIVERY OF THIS PRODUCT SHALL BE LIABLE FOR ANY DIRECT, INDIRECT, CONSEQUENTIAL OR INCIDENTAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE SUCH PRODUCT. WE RESERVE THE RIGHT TO CHANGE THE CONTENTS, PRICE, PACKAGING, AND OTHER ASPECTS OF THIS PRODUCT WITHOUT PRIOR NOTICE.