



1979-1993 Ford Mustang

Part # - XFO M3 L

**TRUNK LID**

Hatchback/T-Top

Install Dynamat as shown, align with existing brackets, supports, and holes.

Install all parts on (open) Trunk Lid of vehicle as shown.

**REAR (TOP)**

**DRIVER SIDE**



**PASSENGER SIDE**

**FRONT OF VEHICLE (BOTTOM)**



WARRANTY: Dynamat, Inc. guarantees the contents of the container only for a period of one year from the date of purchase. If product is found to be defective, replacement material will be furnished free of charge or a refund of the material cost will be given at manufacturer option. Due to the fact that Dynamat, Inc. has no control over proper surface preparation, application or installation methods, no guarantee as to results is offered, expressed, or implied. Dynamat Inc.'s liability for claims of any kind is strictly limited to the purchase price of the material.