PASSENGER SIDE

## 1979-1993 Ford Mustang TRUNK LID

Coupe (notchback) and Convertible

Install Dynamat as shown, align with existing brackets, supports, and holes.

Install all parts on (open) Trunk Lid of vehicle as shown.

## **REAR (TOP)**



FRONT OF VEHICLE (BOTTOM)