



1992-96 Bronco Door Panel Reinforcement Brackets

Tools Needed:

Phillips head screwdriver	Vice grips
Flat head screwdriver	Sandpaper
Trim removal tool	Wire brush
Assortment of clamps	Cleaning supplies



1. Start by opening the door and rolling down the window. This will allow you to grab the door in more areas around the panel itself for the removal process.
2. Crack the corner vent widow.
3. Starting at the power window switch, remove the Phillips head screw holding it in place.
4. Lift the switch and bezel from the panel and flip it over to access the retaining screws and the mirror switch connector on the backside.
5. Using a small flat blade screwdriver, release the connector on the mirror switch. Remove all three of the Phillips head screws holding the switch to the bezel.
6. Remove the screw at the door pull area.
7. Starting on the top corner of the panel, locate the long Phillips head screw in the recessed hole and remove it from the panel. *(Since these have a few different screws that will be different sizes, use a small scrap piece of cardboard and label each of the screws coming out to keep track of these. Label these accordingly for their corresponding hole or location.)*
8. Moving to the lower edge of the door, locate all of the attaching screws and remove these from the door.
9. Once you have all of the attaching screws out of the door release all of the door panel push pins that hold the panel in place.
(There will be three of these along the leading edge, two on the backside, and one in the center by the handle)
10. Using a trim removal tool work around the panel and release these from the door.
11. Once the panel is free, remove the door light by turning it counter clockwise. Back the electrical connectors down while lifting the door panel up and out to fully remove from the door.
12. Remove the factory inner door belt weatherstrips by gently releasing the tabs along the panel, set aside.
13. Prep the door panel for the adhesive. Clean all excess dirt with a simple cleaning solution and a paper towel.
(Verify that you have the correct bracket. They are side specific.)
14. Pull back the jute padding to give you room for the bracket. Hold this in place by pinning it back with some picks and pins
15. Scuff the surface with a combination of a wire brush and some fine sandpaper to give the bracket a rough surface to adhere too.
(Clean all remaining dust from any sanding before applying the adhesive. Have clamps or vice grips ready.)

16. Open the adhesive and apply it to the door panel where the bracket will make contact. *(This can be verified by dry-fitting the bracket first.)* Apply the adhesive to the bracket as well.
17. Once the glue is spread onto the panel and the bracket, position the bracket into its proper location.
18. Use an assortment of clamps and carefully clamp the bracket to the door panel. Make sure that you apply enough clamps across the entire bracket and that they are evenly spaced.
19. Once everything is fully clamped down, allow at least 1 hour minimum for proper dry time.
20. After everything has dried, remove clamps and check work.
21. Reinstall the inner door belt.
22. Reinstall door panel and all attaching hardware and complete all electrical connections of the window switch.
23. Repeat these steps for the other door panel.



**WATCH THE INSTALL
VIDEO HERE!**

Disclaimer

By using this instruction sheet, you agree that other than as expressly stated in the LMR Terms and Conditions (Agreement) or as required by the laws of the state of Texas or applicable United States federal law (Applicable Law), this instruction sheet is provided "AS IS" and LMR does not make any specific representations or warranties about this instruction sheet. For example, LMR does not make any warranties about: (a) the content provided in this instruction sheet; (b) any specific features of this instruction sheet, or its accuracy, reliability, or ability to meet your needs. The knowledge and experience level of users of this instruction sheet vary widely; if you do not have adequate knowledge and experience to use this instruction sheet and safely accomplish the tasks described, please hire a professional to assist you for your safety and the safety of your vehicle and others.

Limitation of Liability

Except as required by Applicable Law, LMR, its affiliates, officers, directors, employees and agents will not be responsible for any loss of profits, revenues, business opportunities, goodwill, or anticipated savings, indirect or consequential loss, punitive damages caused by:

- Errors, mistakes, or inaccuracies in this instruction sheet
- Personal injury or property damage resulting from your use of this instruction sheet

This limitation of liability provision applies to any claim regardless of whether the claim asserted is based on warranty, contract, tort or any other legal theory.

Use this information at your own risk. Any injury, damage, or loss that may result from use of the tools, equipment, products, or information contained in this instruction sheet is the sole responsibility of the user.

Indemnity

To the extent permitted by Applicable Law, you agree to defend, indemnify and hold harmless LMR, its Affiliates, officers, directors, employees, agents, information providers, licensors, and other partners from and against any and all claims, damages, obligations, losses, liabilities, costs or debt, and expenses (including but not limited to attorney's fees) arising from: (i) your use of and access to this instruction sheet; (ii) your violation of any term of the Agreement; (iii) your violation of any third party right, including without limitation any copyright, property, or privacy right; or (iv) any claim that your actions caused damage to LMR or a third party. The defense and indemnification obligations will survive this Agreement and your use of this instruction sheet.

FIND YOUR NEXT MOD! SHOP 1000s OF PARTS ONLINE 24/7 @ LMR.COM