SOLARWING INSTRUCTIONS:

IMPORTANT!

Your Solarwing II comes with a new type of Mounting Surface Preparation Fluid. The new "Prep-Fluid" displaces moisture and creates a protective barrier which the mounting tape bonds to immediately. Therefore it is extremely important that you mount the Solarwing II properly the first time. For ease and accuracy we strongly recommend that 2 people mount the wing.

SOLARWINGT CREATES PROTECTIVE MOISTURE BARRIER YAPE PORES OF GLASS PORES OF GLASS WE FALL PREP FLUP

PLEASE READ AND FOLLOW THE INSTRUCTIONS CAREFULLY BEFORE MOUNTING THE WING.

USEFULL MATERIALS: Ruler and masking tape or marker.

PREPARE MOUNTING SURFACE OF CAR:

- 1. Clean mounting surface with a solution of mild soap and water then wipe dry with a clean cloth.
- 2. Wipe mounting surface with one of the supplied alcohol pads and wipe dry with a clean cloth.
- 3. Clip off a corner of the prep-fluid package, apply to a supplied alcohol pad or clean cloth, and wipe the mounting surface. Allow prep-fluid to AIR DRY for 5-minutes.

PRE-MOUNT/LOCATE & MARK POSITION:

NOTE: Most wings mount directly to the glass and require a 1/8" gap at the top and equal spacing on the sides, between the wing and the inside edge of the molding or the edge of the glass.

EXCEPTION: On the Camaro and Firebird the wing mounts to, and is flush with the edges of, the rear window molding.

 Locate and place wing on the rear window according to the instructions above, then mark the corner/edge locations with tape or marker.



MOUNTING/2-PEOPLE

- Remove backing from mounting tape. Be careful not to touch the tape or get it dirty.
- 2. Line up corners with tape marks and place corners down first, then
- 3. Ease wing back/down into position.
- 4. Press down firmly on mounting flange all around wing to ensure seating of tape.



MOUNTING/ONE-PERSON:

 Peel away protective backing approximately ³/₄" to 1" from both corners of mounting tape. Fold backing at a 45° angle so tape extends beyond the mounting flange.



2. Position top edge of wing on window then lower til corners line up with locating marks. Set in place so tape adheres.



 Grasp top/front edge of wing with one hand and lift (approximately ½") enough to take pressure off mounting tape. With other hand peel backing from tape and lower wing to car.



 Press down on mounting flange all around wing to ensure seating of tape.

NOTE: Allow mounting tape to cure at least 24 hours before washing car.

LIMITED All components of this product have a LIMITED LIFETIME WARRANTY from date of purchase to be free of manufacturer's defects in material and craftsmanship. Damage due to improper installation or road hazards is not covered. Manufacturer's obligation shall be to replace the product proved to be defective. Proof of purchase is necessary for the replacement of any warrantable G.T. StylingTM product.

G.T. STYLING · Consumer Warranty Claims · (714) 630-6561

INST 9048A