


1993 COBRA STYLE GRILLE INSERT INSTALLATION INSTRUCTIONS

Prop. 65 Warning for California Residents



Instructions

1. Trim provided template (pg. 2).
2. Tape the template to the passenger side of the bumper cover.
3. Trace area to be cut out of bumper cover with a marker.
4. Remove template and tape to the driver side of the bumper cover.
5. **CAREFULLY** cut the bumper cover along the lines that were traced from the template. Make small cuts and trim as needed.
6. On the insert, there is a small stud located on the driver side. You must drill out a hole in your bumper cover or shave it off to compensate.
7. Scuff, prime, and paint insert.
8. Take note where the threaded stud is mounted on the cobra grille. Mark the spot where the threaded stud touches the bumper cover and grill a 1/4 inch hole.
9. Install provided tape on back of grille insert where it contacts the front bumper cover.
10. Clean area where the Cobra grille insert meets the bumper cover with alcohol.
11. **CAREFULLY** position and apply Cobra grille insert to bumper cover. Apply gentle pressure with your hand to smooth insert and evenly apply tape.
12. Install the stud of the pony logo through the insert and into the bumper cover.
13. Install and tighten nut for pony on the backside of the bumper cover. Do **NOT** overtighten!



See page 2 for cut-out template.

Disclaimer

By using this instruction sheet, you agree that other than as expressly stated in the LMR Terms and Conditions (Agreement) or as required by the laws of the state of Texas or applicable United States federal law (Applicable Law), this instruction sheet is provided "AS IS" and LMR does not make any specific representations or warranties about this instruction sheet. For example, LMR does not make any warranties about: (a) the content provided in this instruction sheet; (b) any specific features of this instruction sheet, or its accuracy, reliability, or ability to meet your needs. The knowledge and experience level of users of this instruction sheet vary widely; if you do not have adequate knowledge and experience to use this instruction sheet and safely accomplish the tasks described, please hire a professional to assist you for your safety and the safety of your vehicle and others.

Limitation of Liability

Except as required by Applicable Law, LMR, its affiliates, officers, directors, employees and agents will not be responsible for any loss of profits, revenues, business opportunities, goodwill, or anticipated savings, indirect or consequential loss, punitive damages caused by:

- Errors, mistakes, or inaccuracies in this instruction sheet
- Personal injury or property damage resulting from your use of this instruction sheet

This limitation of liability provision applies to any claim regardless of whether the claim asserted is based on warranty, contract, tort or any other legal theory.

Use this information at your own risk. Any injury, damage, or loss that may result from use of the tools, equipment, products, or information contained in this instruction sheet is the sole responsibility of the user.

Indemnity

To the extent permitted by Applicable Law, you agree to defend, indemnify and hold harmless LMR, its Affiliates, officers, directors, employees, agents, information providers, licensors, and other partners from and against any and all claims, damages, obligations, losses, liabilities, costs or debt, and expenses (including but not limited to attorney's fees) arising from: (i) your use of and access to this instruction sheet; (ii) your violation of any term of the Agreement; (iii) your violation of any third party right, including without limitation any copyright, property, or privacy right; or (iv) any claim that your actions caused damage to LMR or a third party. The defense and indemnification obligations will survive this Agreement and your use of this instruction sheet.

CUT OUT TEMPLATE ALONG BLACK LINES.

THIS SIDE OF THE PAGE IS FOR THE PASSENGER SIDE (RIGHT SIDE).

THIS AREA OF THE BUMPER COVER MAY REQUIRE SOME TRIMMING WHEN PREFITTING COBRA GRILLE.

*** CAUTION ***
TRIM SMALL PORTIONS AT A TIME.



THIS AREA OF THE BUMPER COVER MAY REQUIRE SOME TRIMMING WHEN PREFITTING COBRA GRILLE.

*** CAUTION ***
TRIM SMALL PORTIONS AT A TIME.



CUT OUT TEMPLATE ALONG BLACK LINES.

THIS SIDE OF THE PAGE IS FOR THE DRIVERS SIDE (LEFT SIDE).

HOLE FOR LEFT SIDE (ONLY)

