



1731 Throncroft, Troy, MI 48084

Mustang 2005 & later one piece driveshaft installation instructions

- 1) First remove factory two piece driveshaft, discard all except the (4) fasteners that mount factory shaft to transmission output flange.
- 2) Next install Adapter Plate (part-b) into rear CV pinion yoke with (part-d) M10 SHCS, use Loctite on threads (not included).
- 3) Next install new driveshaft (part-a) with slip-spline towards rear of car, use the existing factory hardware to mount shaft to transmission output flange and use 7/16 SHCS (part-c) to mount rear of shaft to adapter plate (part-b), use Loctite on all fasteners.

Note: Torque M10 fasteners (part-d) to approximately 25 lb-ft,
 Torque 7/16 fasteners (part-d) to approximately 35 lb-ft.

Parts List:

- a) Driveshaft
- b) Adapter Plate
- c) 7/16-20 x 1" Lg. Soc. Hd. Scr. (4)
- d) M10x1.5 x 30.0 Lg. Soc. Hd. Scr. (6)

