



Steeda S550 Hardcore Strut Tower Tool

Installation Instructions for Part #: 555-8920



1. Make sure strut shaft is in the center of the tower hole before you start. You might need to loosen the 3 camber plate bolts to do this.
2. Attach the hole saw blade to the proper drill arbor (5/8"-18) with the pilot drill bit removed.
3. Align the hole saw insert with the strut tower hole with the strut shaft going into the hole in the Steeda custom tool. Drill the strut tower. **Note: it will make it easier to cut hole if you angle the saw to start the cut, then drive it in straight.**
4. Clean debris from the upper strut mount with a vacuum or compressed air. File any rough edges and use touch-up paint to prevent rusting.
5. Now you can adjust for max camber for track days.

Before running max camber



Now running max camber

