


SVE-22404LP-K



1979-93 Mustang Low Profile Door Handle Kit

If painting the Low Profile Door Handles, follow the steps on the installation video.

1. Remove the door panel and tape off the area around the door handle.
2. Grab your hammer and drift pin and knock the small hardened steel mandrels that are left in the original rivets.
3. Grab your drill and drill through the head of the rivet with a 1/4" drill bit making sure to stop once the head pops loose. **DO NOT DRILL ALL THE WAY THROUGH.**
4. Now that the rivet heads are removed, you can go ahead and push down on the inside rod and remove the handle from the door.
5. Place the door handles face down on a clean microfiber.
6. Apply a small amount of blue thread locking compound to the small button head hex drive screw.
7. Position the handle arm in the correct orientation, then install and tighten the screw.
8. Repeat these steps for the other handle. **NOTE:** *Arms should be on opposite sides of handles.*
9. With the door handle removed from the car, drill out the two holes in the door with a 5/16" uni-bit. This allows just a little more room to situate the handle within the door.
10. Wipe the area clean with a detail spray and microfiber towel.
11. Carefully position the corresponding handle assembly into place for the side of the car that you're working on.
12. Finger-tighten the two retaining nuts.
13. Move the handle within the door cup until it's even.
14. Go ahead and fully tighten the two nuts.
15. Apply a small amount of blue thread locking compound to the set screw.
16. Lift up the handle and reinstall the set screw.
17. Turn the set screw in or out depending on the clocking of the handle.
18. Whenever the handle is even, let the blue thread locking compound fully cure.
19. Remove the factory rod from the latch.
20. Install the nylon flange nut onto the new latch rod and run it all the way to the bottom of the threads.
21. Now, install the new rod into the handle arm, then insert it into the latch.
22. Turn the nylon nut with your fingers until it barely makes contact with the handle arm. *(cont.)*

23. Test for operation and then repeat these same steps for the other side.
24. Reinstall the door panel and its associated components.
25. After that, you're good to go!

WATCH THE INSTRUCTION VIDEOS HERE

Scan or click to view!



**Low Profile Door
Handle Installation**



**Fox Body Door
Handle Removal**

Disclaimer

By using this instruction sheet, you agree that other than as expressly stated in the LMR Terms and Conditions (Agreement) or as required by the laws of the state of Texas or applicable United States federal law (Applicable Law), this instruction sheet is provided "AS IS" and LMR does not make any specific representations or warranties about this instruction sheet. For example, LMR does not make any warranties about: (a) the content provided in this instruction sheet; (b) any specific features of this instruction sheet, or its accuracy, reliability, or ability to meet your needs. The knowledge and experience level of users of this instruction sheet vary widely; if you do not have adequate knowledge and experience to use this instruction sheet and safely accomplish the tasks described, please hire a professional to assist you for your safety and the safety of your vehicle and others.

Limitation of Liability

Except as required by Applicable Law, LMR, its affiliates, officers, directors, employees and agents will not be responsible for any loss of profits, revenues, business opportunities, goodwill, or anticipated savings, indirect or consequential loss, punitive damages caused by:

- Errors, mistakes, or inaccuracies in this instruction sheet
- Personal injury or property damage resulting from your use of this instruction sheet

This limitation of liability provision applies to any claim regardless of whether the claim asserted is based on warranty, contract, tort or any other legal theory.

Use this information at your own risk. Any injury, damage, or loss that may result from use of the tools, equipment, products, or information contained in this instruction sheet is the sole responsibility of the user.

Indemnity

To the extent permitted by Applicable Law, you agree to defend, indemnify and hold harmless LMR, its Affiliates, officers, directors, employees, agents, information providers, licensors, and other partners from and against any and all claims, damages, obligations, losses, liabilities, costs or debt, and expenses (including but not limited to attorney's fees) arising from: (i) your use of and access to this instruction sheet; (ii) your violation of any term of the Agreement; (iii) your violation of any third party right, including without limitation any copyright, property, or privacy right; or (iv) any claim that your actions caused damage to LMR or a third party. The defense and indemnification obligations will survive this Agreement and your use of this instruction sheet.

FIND YOUR NEXT MOD! SHOP 1000s OF PARTS ONLINE 24/7 @ LMR.COM