



16-20 Mustang GT350 Rock Guard Installation Instructions

This product utilizes factory mounting locations, 3M VHB tape for additional hold and our custom metal clips for this install. Please see the front install details below.

Tools & Supplies Needed

- Body panel clip removal tool
- Alcohol wipes or rubbing alcohol for cleaning
- Masking tape

Front Rock Guards:

1. Turn the steering wheel to move the tire so as to expose the back of the front fender liner
2. Remove the 3 lower panel clips from the fender liner behind the front wheel using a body clip tool.
Note: The upper clip is smaller than the others.
3. Clean the inside edge of the body panel with alcohol and make sure no debris, waxes or polishes remain. *(Important step to make sure the 3M adhesive bonds to the vehicle)*
4. Remove the red backing of the 3M adhesive and insert the upper factory clip while aligning the top corner of the rock guard flush with the fender. Apply pressure to the top side of the clip and move your hand up the rock guard to adhere the rock guard to the body panel. Repeat the step for the lower portion as well. *Note: You want to press the rock guard against the vehicle from the center and move outwards, this will allow the rock guard to confirm to the curve of the vehicle properly.*
5. Insert remaining push clips on the bottom of the rock guard
6. Install 2 metal clips (provided) onto the rock guard, one at the top of the guard and the 2nd midway where the pre-punched hole is. These will wrap around the edge of the body panel of the vehicle and the rock guard for added support.



Any questions email info@zl1addons.com or call PH 858 527 8727