

10-14 Mustang Tow Hook Front

- Remove the bumper cover from vehicle per factory instructions
- Locate the front crash bar and how it mounts to the vehicle on the passenger side
- The two innermost holes will be used for this installation
- Install the M8 bolts with a washer going from front of the vehicle to the rear.
- Place the tow hook receiver **Behind the crash bar** with the welded nut section of the bracket going to the ground as seen in the picture below.
- The bolts previously installed should be going through the receiver.
- Install a washer on each stud and then fasten with the M8 nuts
- Before final reinstallation of bumper onto the vehicle, place the bumper onto the car without fastening any hardware and ensure that the tow hook shaft will pass through a lower grille hole into the welded nut on the receiver.
- If it does not line up, loosen the M8 Nuts and adjust bracket if necessary.
- Reinstall the bumper and fasten it according to factory instructions.
- Install tow hook shaft into receiver followed by the D ring.

