



Mustang 10-14 Wicker Bill Installation

LEAVE PROTECTIVE FILM ON PLASTIC! To install the 2-piece wicker bill, find center of rear spoiler and make a mark to line up center of wicker bill.

FIND DEAD CENTER OF SPOILER, right to left. Position sub spoiler so that the top part of the black sub wicker is even with the top or 1/8 inch below the top of the spoiler. Mark the center hole to drill with marker.

Use a 19/32 drill bit to drill the center. **MAKE SURE YOU DO NOT DRILL TOO FAR IN TO COME OUT THE TOP OF SPOILER!** The spoiler is thin in that part.

Install the one center rivnut with rivnut tool. **THE RIVNUT TOOL DOES NOT TAKE MUCH MOVEMENT TO SET THE RIVNUT!!** You will feel just a small amount and then it will tighten when squeezing.

Install the sub wicker with center bolt and wrap the wicker bill around both sides keeping the wicker bill flat to the top of the spoiler and straight. Also, it helps for 2 people to position both sides evenly at the bottom and mark the holes with marker.

Remove the sub wicker and drill the other holes with 19/32 bit. Install the rest of the rivnuts with rivnuts tool.

Remove plastic cover and install the wicker bill.



Any questions email info@zl1addons.com