



Mustang California Special Wicker Bill Installation

LEAVE PROTECTIVE FILM ON PLASTIC! To install the 2-piece wicker bill, find center of rear spoiler and make a mark to line up center of wicker bill.

FIND DEAD CENTER OF SPOILER, right to left. Position sub spoiler to look like the photo. The bottom of the wicker bill is about 1/8 to 1/4 above the trunk lid. Mark the center hole to drill with marker.

Use a 3/8 drill bit enlarge by reaming a small amount to drill the center hole. You can also use the correct size drill bit 25/64.

Install the one center riv nut with riv nut tool. **THE RIVNUT TOOL DOES NOT TAKE MUCH MOVEMENT TO SET THE RIVNUT!** You will feel just a small amount and then it will tighten.

Install the sub wicker with center bolt and wrap the wicker bill around both sides keeping the wicker bill flat to the top and straight. Also, it helps for 2 people to position both sides evenly at the bottom and mark the holes with marker.

Remove the sub wicker and drill the other holes with 3/8 or 25/64 bit. Install the rest of the riv nuts with riv nut tool.

Remove plastic cover and install the wicker bill.

Any questions email info@zl1addons.com