



## Mustang GT500 Wicker Bill Installation

**LEAVE PROTECTIVE FILM ON PLASTIC!** To install the 2-piece wicker bill, find center of rear spoiler and make a mark to line up center of wicker bill.

**FIND DEAD CENTER OF SPOILER**, right to left. Position wicker bill so that the top part of the wicker bill matches the image below, note you do have some play up and down, but check the sides on how they fade into the spoiler to what you desire. Mark the center hole to drill with marker.



Use a 9/32 drill bit to drill the center. Install the rivnut on the rivnut gun and install into the center location. You may need to ream the 9/32 holes a small amount to get the rivnuts to go in tight. Now squeeze the rivnut tool to tighten up the rivnut, do not over squeeze, one squeeze is typically enough to seat the rivnut.

With the wicker bill attached to the spoiler, wrap it around each side and mark the outer holes using the wicker bill for a template.

Drill the remaining holes with a 9/32 drill bit like the center mount previous done.

Remove plastic cover and re-install the wicker bill with all 10/32 bolts. It is best to tighten from the center and work you way out.

Any questions email [info@zl1addons.com](mailto:info@zl1addons.com)