

## 87-93 Mustang Billet Window Switch Plate Installation



1. Remove the factory retaining screw on existing windows plates.



2. Position the new billet plate over the existing window plate.

3. Fasten the plate with the existing top hole and supplied Phillips screw.



4. Using a 7/64 drill bit and drill, drill a ½" deep pilot hole for the bottom mounting screw. Using the supplied Phillips screw, fasten the bottom of the plate.

Repeat installation instructions for opposite side.

For Convertible version of the Window Plates, this process only applies to the passengers side of the vehicle. The drivers side does not require any drilling, simply fasten the new billet plate over the existing plate, using the supplied screws.