

Wiper Delete Kit Installation (94-04)



To Remove each wiper arm:

1. Lift the wiper arm up to the locked position. Using a flat headed screwdriver, move the locking tab to the locked position.
2. Let the wiper arm rest on the locking tab. Gently remove the arm, it will lift off of the mounting post.
3. Place the billet wiper delete over the mounting post. Using the allen wrench, tighten the allen set screw. Repeat for the opposite side.