

## 1992-96 Bronco Battery Cable Kit

### Cable “A” – Positive Battery Cable (Red)

- A1 - Connects to the positive battery terminal on the battery. *(Figure 1.5)*
- A2 - Connects to the “battery” side of the fender mounted solenoid. *(Figure 1.6)*
- A3 - Connects to the “B+” terminal on the starter solenoid. *(Figure 1.1, 2.1)*

### Cable “B” – Negative Battery Cable (Black)

- B1 - Connects to the negative terminal on the battery. *(Figure 1.4)*
- B2 - Grounds to the stud in the passenger fender apron. *(Figure 1.4)*
- B3 - Grounds to the passenger side of the engine block. *(Figure 1.2)*
- B4 - Grounds to the top side of the passenger side frame rail. *(Figure 1.3)*


### Cable “C” – Alternator Power Wire (Red)

- C1 - Connects to “B+” terminal on the back of the alternator. *(Figure 1.7, 2.2)*
- C2 - Connects to the “battery” side of the fender mounted solenoid. *(Figure 1.6)*
- C3 - Splice into the yellow with white stripe wire near the voltage regulator. Trim back the wire loom if necessary. *(Figure 1.7)*

### Cable “D” – Fender Solenoid to Starter Solenoid Cable (Red)


- D1 - Connects to the “starter” side of the fender mounted solenoid. *(Figure 1.6)*
- D2 - Connects to the “S” (start terminal) on the starter solenoid. *(Figure 1.1, 2.1)*

### Positive Cable




*More diagrams on next page*

## Negative Cable



## Alternator Power Wire



*More diagrams on next page*

## Solenoid to Starter Cable




Figure 1.1




Figure 1.2






Figure 1.3




Figure 1.4




Figure 1.5






Figure 1.6




C2 – Factory power wire shown



**Figure 1.7**



**Figure 2.1 (Off-Vehicle)**



**Figure 2.2 (Off-Vehicle)**



**Disclaimer**

By using this instruction sheet, you agree that other than as expressly stated in the LMR Terms and Conditions (Agreement) or as required by the laws of the state of Texas or applicable United States federal law (Applicable Law), this instruction sheet is provided "AS IS" and LMR does not make any specific representations or warranties about this instruction sheet. For example, LMR does not make any warranties about: (a) the content provided in this instruction sheet; (b) any specific features of this instruction sheet, or its accuracy, reliability, or ability to meet your needs. The knowledge and experience level of users of this instruction sheet vary widely; if you do not have adequate knowledge and experience to use this instruction sheet and safely accomplish the tasks described, please hire a professional to assist you for your safety and the safety of your vehicle and others.

**Limitation of Liability**

Except as required by Applicable Law, LMR, its affiliates, officers, directors, employees and agents will not be responsible for any loss of profits, revenues, business opportunities, goodwill, or anticipated savings, indirect or consequential loss, punitive damages caused by:

- Errors, mistakes, or inaccuracies in this instruction sheet
- Personal injury or property damage resulting from your use of this instruction sheet

This limitation of liability provision applies to any claim regardless of whether the claim asserted is based on warranty, contract, tort or any other legal theory.

Use this information at your own risk. Any injury, damage, or loss that may result from use of the tools, equipment, products, or information contained in this instruction sheet is the sole responsibility of the user.

**Indemnity**

To the extent permitted by Applicable Law, you agree to defend, indemnify and hold harmless LMR, its Affiliates, officers, directors, employees, agents, information providers, licensors, and other partners from and against any and all claims, damages, obligations, losses, liabilities, costs or debt, and expenses (including but not limited to attorney's fees) arising from: (i) your use of and access to this instruction sheet; (ii) your violation of any term of the Agreement; (iii) your violation of any third party right, including without limitation any copyright, property, or privacy right; or (iv) any claim that your actions caused damage to LMR or a third party. The defense and indemnification obligations will survive this Agreement and your use of this instruction sheet.