

Installation Instructions JLT Induction Kit (2010-14 Shelby GT500) #JLTIK-GT500-10

Thank you for purchasing our product. We hope you are satisfied with the look and performance. Take your time and it will be a smooth install.

Please review complete instructions prior to installing.

Step#	
1	Verify you have all of the following parts included in the kit: (1) 5" Silicone coupler, (1) 4.5" Silicone coupler, (2) 80 clamps, (2) 72 clamps, (1) JLT intake tube with PCV fitting and Vacuum Line Fitting
2	Gather all of the following tools needed for the installation: 10mm socket, ratchet, extension, 5/16 nut driver or regular screw driver.
3	Remove the stock intake system by removing the 10mm bolt holding down the airbox, and clamps at the throttle body.
4	Remove the stock intake tube from the airbox.
5	Slide silicon couplers on JLT intake tube, leave clamps loose and install round end onto stock airbox.
6	Install unit on to throttle body and lower into position.
7	Line everything up, bolt up the airbox and lightly snug the clamps on the carbon fiber tube. Plug in the PCV and vacuum lines and you are done.



Thanks for the business. If you have any questions, please e-mail Info@JLTtruecoldair.com or call 757-335-1940. Our hours are Monday-Friday, 8:00am – 5:00pm Eastern Time.

JLT Performance Lifetime Satisfaction Guarantee. We want you to be a JLT Performance customer for life! Your new JLT Performance product is warranted to be free from defects in materials and workmanship for the life of the *original retail purchaser*, subject to the limitations contained in our warranty found here. www.jlttruecoldair.com/warranty

We guarantee workmanship, tunability and even a pathway to discounted upgrades for substantially improved items.

Return Policy: All returns will be subject to a 10%-25% restocking fee. Air Filters will not be accepted for return unless they are in original plastic sealed bag. Please visit www.JLTtruecoldair.com for complete return policy.

<u>Disclaimer:</u> JLT Performance Inc. makes no warranties whatsoever, expressed or implied, oral or written to any purchasers, except the warranty above. JLT Performance Inc. hereby specifically excludes from any implied warranty of merchantability or implied warranty of incidental, secondary, or consequential damages of any kind whatsoever. All purchasers and users of products manufactured by JLT Performance Inc. agree to hold harmless and indemnify JLT Performance Inc. from any and all claims arising from their use. Failure to receive notice of any or the limitations contained in this disclaimer shall not serve to extend liability to JLT Performance Inc. for any claims arising out of use of its products.

Page 1 of 1 8/1/19