



2010-14 Mustang nGauge A/C Vent Mount Kit



Step 1: Remove instrument cluster bezel from dash. It pulls right off.

Step 2: Remove A/C vent from the instrument cluster bezel. There are 4 clips on the chrome ring on the back side that hold it in.

Step 3: Remove chrome ring from black piece of the A/C vent and remove all plastic pieces inside.

Step 4: Re-install chrome ring.

Step 5: Insert the two long screws(50mm) into the center bolt holes on the front plate.

Step 6: Mount the plastic cup that came with your NGauge onto the front plate with the opening for your cable to the left. Do not tighten nuts with excessive force!

Step 7: Insert front plate assembly into A/C vent with JPP face up. Be careful as you place into position and make sure it is lined up correctly from the back as it goes in. It should sit pretty flat in relation to the vent. Some of the vent internals are not flat, so don't try and force the plate to mate up.

Step 8: Install the back plate onto the back of the A/C vent. Make sure that JPP is facing the same orientation as the front plate. There is also an indentation on the rear plate that fits the A/C vent. Install lock washers and nuts. Do not over tighten!

Step 9: Use a rag or cloth to block the A/C vent behind the instrument cluster bezel. Failure to do so could cause damage to your NGauge.

Step 10: Insert the A/C vent assembly back into the gauge cluster bezel.

Step 11: Feed your nGauge cable up behind the dash and out where your gauge cluster is.

Step 12: Feed Cables for your NGauge through the mount from back to front. Make sure wiring is secured how you want behind the dash. Re-install the Gauge cluster bezel to the dash. Don't cut a hole to feed the cable into the A/C vent. It should fit between the A/C vent and air duct in the dash when you install the gauge cluster bezel.

Step 13: Clip the NGauge wires into the back of your NGauge, and clip the NGauge onto the mount.

Disclaimer

By using this instruction sheet, you agree that other than as expressly stated in the LMR Terms and Conditions (Agreement) or as required by the laws of the state of Texas or applicable United States federal law (Applicable Law), this instruction sheet is provided "AS IS" and LMR does not make any specific representations or warranties about this instruction sheet. For example, LMR does not make any warranties about: (a) the content provided in this instruction sheet; (b) any specific features of this instruction sheet, or its accuracy, reliability, or ability to meet your needs. The knowledge and experience level of users of this instruction sheet vary widely; if you do not have adequate knowledge and experience to use this instruction sheet and safely accomplish the tasks described, please hire a professional to assist you for your safety and the safety of your vehicle and others.

Limitation of Liability

Except as required by Applicable Law, LMR, its affiliates, officers, directors, employees and agents will not be responsible for any loss of profits, revenues, business opportunities, goodwill, or anticipated savings, indirect or consequential loss, punitive damages caused by:

- Errors, mistakes, or inaccuracies in this instruction sheet
- Personal injury or property damage resulting from your use of this instruction sheet

This limitation of liability provision applies to any claim regardless of whether the claim asserted is based on warranty, contract, tort or any other legal theory.

Use this information at your own risk. Any injury, damage, or loss that may result from use of the tools, equipment, products, or information contained in this instruction sheet is the sole responsibility of the user.

Indemnity

To the extent permitted by Applicable Law, you agree to defend, indemnify and hold harmless LMR, its Affiliates, officers, directors, employees, agents, information providers, licensors, and other partners from and against any and all claims, damages, obligations, losses, liabilities, costs or debt, and expenses (including but not limited to attorney's fees) arising from: (i) your use of and access to this instruction sheet; (ii) your violation of any term of the Agreement; (iii) your violation of any third party right, including without limitation any copyright, property, or privacy right; or (iv) any claim that your actions caused damage to LMR or a third party. The defense and indemnification obligations will survive this Agreement and your use of this instruction sheet.

FIND YOUR NEXT MOD! SHOP 1000s OF PARTS ONLINE 24/7 @ LMR.COM