







- Step 1: Carefully remove dash trim panel from dash. Clips can easily be damaged. Videos can be found online to properly remove without damaging the panel.
- Step 2: Remove ac vent from dash trim panel by pressing the four chrome tabs that are holding it in the panel.
- Step 3: Place the rear plate that contains the nGauge clamp into the backside of the dash trim panel where the ac vent used to sit. Hold plate in place.
- Step 4: With rear plate held in place, install the front ring with both bolts lined up to the bolt holes. Be sure front ring is installed in the same orientation that it was shipped. Make sure ridges around the bolts are facing the rear plate. Place lock washers and nuts on the back of the bolts. Gently tighten nuts so the mount will still turn in the trim panel.
- Step 5: The mount can be turned for desired angle. Hold dash trim panel out and make sure it is in the correct orientation. Typically placing the black bolts at the 11 o'clock and 5 o'clock position, with the clamping area angled downwards, is a good starting point.
- Step 6: Press nGauge into clamping area of mount. If nGauge doesn't press in easily, loosen clamp bolt on the mount. DO NOT FORCE nGauge in clamping area with clamp tight. Make sure that nGauge is seated flatly against clamping area.
- Step 7: Check orientation of angle and nGauge for desired position. Rotating the mount to the right angles nGauge towards the driver. Rotating the mount to the left angles the nGauge downwards.
- Step 8: Once desired angle is achieved, remove nGauge and tighten black bolts enough to secure mount in place. DO NOT OVER TIGHTEN!
- Step 9: Re-install nGauge into clamping area. Check orientation of the nGauge and tighten clamp bolt to lock nGauge in place. Again, DO NOT OVER TIGHTEN!
- Step 10: Feed OBD2 cable through dash and connect to the nGauge. Tips on how to run cable can be found on YouTube.
- Step 11: Replace dash trim piece with installed nGauge and mount. Enjoy!

By using this instruction sheet, you agree that other than as expressly stated in the LMR Terms and Conditions (Agreement) or as required by the laws of the state of Texas or applicable United States federal law (Applicable Law), this instruction sheet is provided "AS IS" and LMR does not make any specific representations or warranties about this instruction sheet. For example. LMR does not make any warranties about: (a) the content provided in this instruction sheet; (b) any specific features of this instruction sheet, or its accuracy, reliability, or ability to meet your needs. The knowledge and experience level of users of this instruction sheet vary widely; if you do not have adequate knowledge and experience to use this instruction sheet and safely accomplish the tasks described, please hire a professional to assist you for your safety and the safety of your vehicle and others.

I imitation of Liability

Except as required by Applicable Law, LMR, its affiliates, officers, directors, employees and agents will not be responsible for any loss of profits, revenues, business opportunities, goodwill, or anticipated savings, indirect or consequential loss, punitive damages caused by:

- Errors, mistakes, or inaccuracies in this instruction sheet
- Personal injury or property damage resulting from your use of this instruction sheet

This limitation of liability provision applies to any claim regardless of whether the claim asserted is based on warranty, contract, tort or any other legal theory.

Use this information at your own risk, Any injury, damage, or loss that may result from use of the tools, equipment, products, or information contained in this instruction sheet is the sole responsibility of the user.

To the extent permitted by Applicable Law, you agree to defend, indemnify and hold harmless LMR, its Affiliates, officers, directors, employees, agents, information providers, licensors, and other partners from and against any and all claims, damages, obligations, losses, liabilities, costs or debt, and expenses (including but not limited to attorney's fees) arising from: (i) your use of and access to this instruction sheet; (ii) your violation of any term of the Agreement; (iii) your violation of any third party right, including without limitation any copyright, property, or privacy right; or (iv) any claim that your actions caused damage to LMR or a third party. The defense and indemnification obligations will survive this Agreement and your use of this instruction sheet.