

1979-93 Mustang Pedal Assembly Spacer Kit Installation Instructions

Prop. 65 Warning for California Residents
WARNING: This product may contain chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

1. Remove any bracket and/or component that is secured to the pedal assembly. Then, remove the four retaining nuts securing the pedal assembly to the firewall. Extensions and swivel sockets are recommended.
2. Next, remove the remaining retaining screws securing the pedal assembly to the underside of the dash. Use a small pry bar to help give some leverage so the pedal assembly can be maneuvered out from underneath the dash.
3. With the pedal assembly free, remove the old spacer and install the new assembly. Be sure to orient the spacer as shown in photo with the flat side facing you for the correct installation.
4. Re-position the pedal assembly over the studs on the underside of the dash. Tighten the top retaining bolt from step 2 to hold the pedal assembly in place, then reattach anything that was attached to the pedal assembly.
5. Reinstall the four pedal assembly to firewall retaining nuts.
6. On the topmost threaded studs on the pedal assembly, retighten the previously removed nuts to secure the pedal assembly to the underside of the dash.
7. Retighten the previously removed retaining hardware, and double-check your work if needed.



Disclaimer

By using this instruction sheet, you agree that other than as expressly stated in the LMR Terms and Conditions (Agreement) or as required by the laws of the state of Texas or applicable United States federal law (Applicable Law), this instruction sheet is provided "AS IS" and LMR does not make any specific representations or warranties about this instruction sheet. For example, LMR does not make any warranties about: (a) the content provided in this instruction sheet; (b) any specific features of this instruction sheet, or its accuracy, reliability, or ability to meet your needs. The knowledge and experience level of users of this instruction sheet vary widely; if you do not have adequate knowledge and experience to use this instruction sheet and safely accomplish the tasks described, please hire a professional to assist you for your safety and the safety of your vehicle and others.

Limitation of Liability

Except as required by Applicable Law, LMR, its affiliates, officers, directors, employees and agents will not be responsible for any loss of profits, revenues, business opportunities, goodwill, or anticipated savings, indirect or consequential loss, punitive damages caused by:

- Errors, mistakes, or inaccuracies in this instruction sheet
- Personal injury or property damage resulting from your use of this instruction sheet

This limitation of liability provision applies to any claim regardless of whether the claim asserted is based on warranty, contract, tort or any other legal theory.

Use this information at your own risk. Any injury, damage, or loss that may result from use of the tools, equipment, products, or information contained in this instruction sheet is the sole responsibility of the user.

Indemnity

To the extent permitted by Applicable Law, you agree to defend, indemnify and hold harmless LMR, its Affiliates, officers, directors, employees, agents, information providers, licensors, and other partners from and against any and all claims, damages, obligations, losses, liabilities, costs or debt, and expenses (including but not limited to attorney's fees) arising from: (i) your use of and access to this instruction sheet; (ii) your violation of any term of the Agreement; (iii) your violation of any third party right, including without limitation any copyright, property, or privacy right; or (iv) any claim that your actions caused damage to LMR or a third party. The defense and indemnification obligations will survive this Agreement and your use of this instruction sheet.