



**1979-1986 Mustang Hatchback Interior Screw Kit  
LRS-7986HB-K**

<b>Kit</b>	<b>Location</b>	<b>Quantity</b>
L01	Quarter Panel	8
L01	Rear Seat Hinge	7
L01	Rh Dash Housing	1
L01	Upper "A" Pillar Cover	4
L01	Inner Taillight Panel	3
L02	Coat Hook	2
L02	Quarter Panel	6
L02	Rear Hatch Upper Cover ('84-'86)	2
L03	Quarter Panel	10
L03	Inner Taillight Panel	2
L03	A Pillar	2
L04	Inside Mirror Cover	2
L05	Speaker Grille	8
L05	Shock Access Hole Cover	2
L06	Cargo Cover Latch	4
L06	Scuff Plate	8
L06	Column Cover	4
L06	Door Armrest Pad	4
L07	Inner Taillight Panel	2
L07	Rear Hatch Upper Cover	2
L08	Upper Roof Panel	4
L08	Lower "A" Pillar Cover	2
L08	Seat Latch Bezel	2
L08	Window/Lock Switch Covers	4
L09	Seat Latch Bezel	6
L10	Lower Dash Cover	2
L11	Latch Release Handle	2
L12	Rear Seat Frame	3
L12	Upper Dash Pad	4
L13	Cargo Cover Hook ('79-'82)	4
L14	Spare Tire Cover Dowel	2
L14	Lower Dash Housing	7
L15	Kick Panel	2
L16	Instrument Bezel	3
L17	Visor Bracket ('79-'84 Uses 6, '85-'86 Uses 4)	6
L18	Lower Dash Cover	2
L18	Upper Dash Pad	4
L19	Side Of Dash Housing	4
L20	Instrument Housing	4
L20	Amplifier Switch	1
L21	Sun Visor Clip ('84-'86)	2
L22	Door Handle Bezels	2
L22	Dome Light Housing	3
L22	Seat Hinge Cover	4
L23	Bug Eye Map Light Housing	2