






1994-04 A/C Vent Register Anti-Rattle Kit

- 1. Remove Shift Knob (if equipped)
- 2. Remove Shifter Bezel
- 3. Disconnect Cigarette Lighter Electrical Connection from the Shifter Bezel
- 4. Carefully Remove the AC/Radio Control Bezel
- 5. Disconnect the 3 electrical connections at the bottom of the AC/Radio Control Bezel (Fog Lights, Traction Control, and Defrost)
- 6. Carefully use a pick or plastic pry tool from the back side of the AC Vents and pry on the retaining tabs to remove them from the AC/Radio Control Bezel. Unclip one retaining tab at a time to reduce the chance of damage.
- 7. Thoroughly clean the vents and bezel to remove any remaining adhesive, debris, or dust build up
- 8. Install the provided foam strips around the end of the bezel where it seals to the HVAC duct inside of the dash. Once the strips are wrapped around the bezel, they will need to be trimmed to fit.
- 9. Cut the rectangle felt swabs (A) in half, apply them to each side of the vents.
- 10. Reinstall the vents into the AC/Radio Control Bezel
- Reinstall all components in reverse order they were removed.







Disclaimer

By using this instruction sheet, you agree that other than as expressly stated in the LMR Terms and Conditions (Agreement) or as required by the laws of the state of Texas or applicable United States federal law (Applicable Law), this instruction sheet is provided "AS IS" and LMR does not make any specific representations or warranties about this instruction sheet. For example, LMR does not make any warranties about: (a) the content provided in this instruction sheet; (b) any specific features of this instruction sheet, or its accuracy, reliability, or ability to meet your needs. The knowledge and experience level of users of this instruction sheet vary widely; if you do not have adequate knowledge and experience to use this instruction sheet and safely accomplish the tasks described, please hire a professional to assist you for your safety and the safely of your vehicle and others.

Limitation of Liability

Except as required by Applicable Law, LMR, its affiliates, officers, directors, employees and agents will not be responsible for any loss of profits, revenues, business opportunities, goodwill, or anticipated savings, indirect or consequential loss, punitive damages caused by:

- Errors, mistakes, or inaccuracies in this instruction sheet
 Personal injury or property damage resulting from your use of this instruction sheet
- This limitation of liability provision applies to any claim regardless of whether the claim asserted is based on warranty, contract, tort or any other legal theory.

Use this information at your own risk, Any injury, damage, or loss that may result from use of the tools, equipment, products, or information contained in this instruction sheet is the sole responsibility of the user.

Indemnity

To the extent permitted by Applicable Law, you agree to defend, indemnify and hold harmless LMR, its Affiliates, officars, directors, employees, agents, information providers, licensors, and other partners from and against any and all claims, damages, obligations, losses, liabilities, costs or debt, and expenses (including but not limited to attorney's fees) arising from: (i) your use of and access to this instruction sheet; (ii) your violation of any term of the Agreement; (iii) your violation of any third party right, including without limitation any copyright, property, or privacy right; or (iv) any claim that your actions caused damage to LMR or a third party. The defense and indemnification obligations will survive this Agreement and your use of this instruction sheet.