

1982-95 OFF-ROAD IDLER BRACKET INSTALLATION INSTRUCTIONS



Instructions

1. Remove hose attached to the back of the factory smog pump.
2. Remove the serpentine drive belt.
3. Remove the bolt from the bottom rear of the smog pump. Do not remove the metal brace attached to the timing cover.
4. Remove the top bolt from the smog pump.
5. Remove smog pump from the aluminum bracket.
6. Place off-road idler bracket in its place and loosely install the top bolt.
7. Position the idler bracket and line up the bottom rear hole and loosely install the bolt.
8. Tighten both bolts and reinstall the serpentine drive belt.
9. Remove rubber smog hoses with valves and plug the vacuum lines.
10. Remove the metal crossover tube from the rear of the cylinder heads & use LRS-6086AK to plug the holes in the cylinder heads.
11. Remove the metal tube going to the H-pipe and pinch off the H-pipe opening with a pair of pliers,
or weld the hole shut.



NOTE: *1994-95 Mustangs will require minor clearancing of the idler & accessory bracket to clear the alternator. This idler bracket is **NOT** intended for use on emission-controlled vehicles.*

Disclaimer

By using this instruction sheet, you agree that other than as expressly stated in the LMR Terms and Conditions (Agreement) or as required by the laws of the state of Texas or applicable United States federal law (Applicable Law), this instruction sheet is provided "AS IS" and LMR does not make any specific representations or warranties about this instruction sheet. For example, LMR does not make any warranties about: (a) the content provided in this instruction sheet; (b) any specific features of this instruction sheet, or its accuracy, reliability, or ability to meet your needs. The knowledge and experience level of users of this instruction sheet vary widely; if you do not have adequate knowledge and experience to use this instruction sheet and safely accomplish the tasks described, please hire a professional to assist you for your safety and the safety of your vehicle and others.

Limitation of Liability

Except as required by Applicable Law, LMR, its affiliates, officers, directors, employees and agents will not be responsible for any loss of profits, revenues, business opportunities, goodwill, or anticipated savings, indirect or consequential loss, punitive damages caused by:

- Errors, mistakes, or inaccuracies in this instruction sheet
- Personal injury or property damage resulting from your use of this instruction sheet

This limitation of liability provision applies to any claim regardless of whether the claim asserted is based on warranty, contract, tort or any other legal theory.

Use this information at your own risk. Any injury, damage, or loss that may result from use of the tools, equipment, products, or information contained in this instruction sheet is the sole responsibility of the user.

Indemnity

To the extent permitted by Applicable Law, you agree to defend, indemnify and hold harmless LMR, its Affiliates, officers, directors, employees, agents, information providers, licensors, and other partners from and against any and all claims, damages, obligations, losses, liabilities, costs or debt, and expenses (including but not limited to attorney's fees) arising from: (i) your use of and access to this instruction sheet; (ii) your violation of any term of the Agreement; (iii) your violation of any third party right, including without limitation any copyright, property, or privacy right; or (iv) any claim that your actions caused damage to LMR or a third party. The defense and indemnification obligations will survive this Agreement and your use of this instruction sheet.