



5.0L A/C & Power Steering Delete Bracket

- A - Long Spacer**
- B - Medium Spacer**
- C - Short Spacer**
- D - 6.5" Bolt & Washer**
- E - 4.5" Bolt & Washer**



Due to the numerous aftermarket pulley manufacturers and the vast number of different pulley sizes available, you must measure and verify the belt length that is needed for your specific application.

1. Remove your existing belt, A/C, & power steering brackets if they are still installed.
2. Next, position the bracket into place. Please refer to the attached images for proper placement.
3. Install the corresponding spacers and hardware to secure the bracket to the engine. Please refer to the attached images for proper spacer and bolt locations.
4. Next, once the bracket is in place, install the idler pulley using Spacer C and the supplied 7/16" bolt, washer, & retaining nut.
5. Once the pulley is fully installed, double check to make sure that all hardware is fully tightened.
6. Now that all the brackets are in place, you can now install the new proper length belt.

Disclaimer

By using this instruction sheet, you agree that other than as expressly stated in the LMR Terms and Conditions (Agreement) or as required by the laws of the state of Texas or applicable United States federal law (Applicable Law), this instruction sheet is provided "AS IS" and LMR does not make any specific representations or warranties about this instruction sheet. For example, LMR does not make any warranties about: (a) the content provided in this instruction sheet; (b) any specific features of this instruction sheet, or its accuracy, reliability, or ability to meet your needs. The knowledge and experience level of users of this instruction sheet vary widely; if you do not have adequate knowledge and experience to use this instruction sheet and safely accomplish the tasks described, please hire a professional to assist you for your safety and the safety of your vehicle and others.

Limitation of Liability

Except as required by Applicable Law, LMR, its affiliates, officers, directors, employees and agents will not be responsible for any loss of profits, revenues, business opportunities, goodwill, or anticipated savings, indirect or consequential loss, punitive damages caused by:

- Errors, mistakes, or inaccuracies in this instruction sheet
- Personal injury or property damage resulting from your use of this instruction sheet

This limitation of liability provision applies to any claim regardless of whether the claim asserted is based on warranty, contract, tort or any other legal theory.

Use this information at your own risk. Any injury, damage, or loss that may result from use of the tools, equipment, products, or information contained in this instruction sheet is the sole responsibility of the user.

Indemnity

To the extent permitted by Applicable Law, you agree to defend, indemnify and hold harmless LMR, its Affiliates, officers, directors, employees, agents, information providers, licensors, and other partners from and against any and all claims, damages, obligations, losses, liabilities, costs or debt, and expenses (including but not limited to attorney's fees) arising from: (i) your use of and access to this instruction sheet; (ii) your violation of any term of the Agreement; (iii) your violation of any third party right, including without limitation any copyright, property, or privacy right; or (iv) any claim that your actions caused damage to LMR or a third party. The defense and indemnification obligations will survive this Agreement and your use of this instruction sheet.