

**PART NO. 72062**

**Instruction Sheet**

## **MUSTANG COBRA REAR XAXIS™ BALL JOINT KIT**

*This part should only be installed by personnel who have the necessary skill, training and tools to do the job correctly and safely. Incorrect installation can result in personal injury, vehicle damage and / or loss of vehicle control*

**Plan Ahead - Read All Instructions BEFORE Installing Part**

*Always check for loose or worn parts, tire pressure and odd tire wear patterns.*

1. Raise vehicle and support with jack stands.  
Remove rear tire/wheel assemblies.
2. Disassembling one side at a time, remove rear upper control arm to knuckle bolt. Separate knuckle from control arm.
3. Remove retaining ring from cross axis ball joint.  
*Note orientation of flange, as you will need to install SPC xAxis joints in same direction.*
4. Using supplied press tools with C-frame press or similar, remove existing cross axis ball joint.
5. Press SPC xAxis joint into knuckle until fully seated and install provided retaining ring, ensuring ring is fully seated in groove.
6. Line up ball joint with upper control arm, reinstall bolt hardware and torque to manufacturer's specification.
7. Repeat steps 2-6 for remaining ball joints.
8. Reinstall tire and wheel assemblies, lower vehicle and road test.

**NOTE: A 4-Wheel alignment may be necessary after installation.**

*Always check for proper clearance between suspension components and other components of the vehicle.*



**Specialty  
Products  
Company®**

P.O. Box 923 • Longmont, CO 80502 • (303) 772-2103  
www.specprod.com • www.spcperformance.com  
Email: info@specprod.com

**Toll Free Technical Hot Line: 1-800-525-6505**

ECN#1941

©2015 Specialty Products Co. • Printed in U.S.A. • Form No. 980621 • Rev.9/15