



STEEEDA

2015 Ford Mustang G-Trac Brace

& Extreme G-Trac Brace

Instructions for 555-5531 & 555-5532

Tools Needed:

1. 22mm socket or wrench
2. 12mm allen wrench, or socket

Installation

1. Raise the car off the ground by the chassis, and place on jack stands (if not using a hoist). Use caution operating a lift, or jack stands, to ensure the car is stable and safe to work around and underneath.
2. Place the provided sub frame spacers into the rear holes of the sub frame. (Once the brace has been installed and tightened, the installation wire can be broken off.) See figure 1.

Note: If the Extreme G-Trac Brace is being installed (figure 3), go to the next step; if the regular G-Trac Brace is being installed (figure 2), go to step 6.

3. Place the brace up in place, and start the 14mm x 80mm long bolts in the front mounting sleeves. Do not tighten them at this time.
4. Install the 14mm x 65mm long bolts into the rear, placing a washer, and the lock nut on top of the sub frame. **Please note, cars vary slightly from car to car. Some tweaking might be required for proper fitment**
5. Torque the front mounting bolts to 55-60ft-lbs.
6. Torque the rear mounting bolts to 55-60ft-lbs.
7. Break the installation wire off of the rear mounting sleeve.

